
PARKER MOTOR REPLACEMENT

WHEN REPLACING THIS STYLE OF MOTOR THE O-RING PROVIDED WILL NEED TO BE USED ON THE REPLACEMENT MOTOR. A COUPLING LINKS THE MOTOR TO THE PUMP ASSEMBLY. THE COUPLING MAY BE DISLODGED DURING THE REMOVAL OF THE OLD MOTOR. RE-SEAT THE COUPLING BEFORE REPLACING THE MOTOR.

