

# INSTRUCTION SHEET

## CYLINDER REPLACEMENT W/ WARNING/PRESSURE SWITCH INTERFACE

MAGNETIC JACK WARNING SWITCH  
WITH GRAY PACKARD CONNECTOR

JACK PRESSURE SWITCH

