


**HYDRAULIC LINE CONNECTION DIAGRAM
2000 SERIES LANDING GEAR SYSTEM
4 - POWER-EXTEND/SPRING-RETRACT JACKS**



**IMPORTANT: DO NOT SWAP FITTINGS
OR REVERSE HOSES BETWEEN THE
CAP AND ROD END OF THE LANDING
GEAR JACKS.**